



ADJUSTMENT PROCEDURE

1. KEY DOWN AND ADJUST R2 FOR PROPER DRIVER TX LEVEL.
2. KEY DOWN WITH DRIVER ISO DISABLED AND ADJUST R8 FOR PROPER DRIVER TX LEVEL.
3. SET R24 TO MID-SCALE AND THEN ADJUST R20 FOR MODERATE DRIVER VOICE INTERCOM LEVEL.
4. SET RX VOLUME TO MODERATE LEVEL AND THEN ADJUST R21 FOR MODERATE LEVEL IN HEADPHONES.

JUMPERS JP1 AND JP2 TO BE INSTALLED FOR STEREO HEADPHONES FOR DRIVER OR PASSENGER RESPECTIVELY.

SV1 HEADER REQUIRES AN ADAPTER CABLE INTERFACES BETWEEN RADIO AND INTERCOM, AND MUST PROVIDE POWER TO THE INTERCOM.

SV2 HEADER REQUIRES AN ADAPTER CABLE THAT INTERFACES BETWEEN THE INTERCOM AND THE BOSE TRIPORT HEADSET.

TITLE: Bose TriPort 2-Place Intercom	
Document Number:	REV:
Date: 7/20/19 10:31 AM	Sheet: 1/1