

ICOM IC-F8101 SIGNALINK USB-6 INTERFACE CABLE, ELECRAFT KAT-500 AND ELECRAFT KPA-500 INTERFACE

NOTES:

1. THE KAT500 TUNE JACK CAN IS A 3.5mm STEREO PLUG, WHICH IS CONNECTED TO THE 3.5mm TUNE JACK ON THE REAR OF THE ELECRAFT KAT500 AUTO-TUNER.
2. THE KAT500_PTT_KEY_IN IS AN RCA MALE PLUG, WHICH IS INSERTED IN THE BOTTOM PTT KEY RCA SOCKET AT THE REAR OF THE ELECRAFT KAT500 AUTO-TUNER. THIS CABLE REPLACES THE CABLE IN FIGURE 3 OF THE ELECRAFT KAT500 MANUAL, WHICH SHOWS A CONNECTION FROM THE ICOM ACC CONNECTOR TO THE KAT500 PTT KEY INPUT JACK.
3. THE KAT500_PTT_KEY_OUT IS THE TOP PTT KEY RCA SOCKET AT THE REAR OF THE KAT500 AUTO-TUNER.
4. THE SIGNALINK USB CONNECTOR IS A FEMALE 6-PIN MINI-DIN CONNECTOR, AND ROUTES SIGNALS IN A MANNER THAT IS COMPATIBLE WITH A LARGE NUMBER OF AMATEUR RADIO TRANSCEIVERS, ALLOWING INTERFACING TO A STANDARD SIGNALINK CONFIGURATION WHERE NO CUSTOM SIGNALINK CABLE IS REQUIRED.

